

How to Print a Status Page.

1. Press System Menu
2. Press Report
3. Press Print Report
4. Press Status Page
5. Press OK